





100% of Actual Size  
Screen Print

POSITION A




100% of Actual Size  
Screen Print

POSITION B




100% of Actual Size  
Pad Print

POSITION D




POSITION E




100% of Actual Size  
Direct Digital

POSITION D




POSITION E



Please note when pen is printed in position D,  
print is not visible when in the notebook holder.




100% of Actual Size  
Pad Print





100% of Actual Size  
Pad Print





100% of Actual Size  
Screen Print (one colour)

